



## c.LOGiC Interface

## C2-MK-AUX

## Compatible with BMW Professional navigation systems without iDrive (MK2-MK4)

### **Product features**

- Full plug and play multimedia interface
- 2 AV-inputs with separate IR-control channels
- control of after-market devices, e.g. DVB-T tuner, DVD-player, DVD-changer, ...
- after-market rear-view camera input (optional adapter is necessary)
- automatic switching to after-market rear-view camera input
- rear-view camera power (+12V max. 1A)
- Rear-seat-entertainment video-output for Video-sources connected to the c.LOGiC
- power-on remote-out trigger-signal (+12V max. 1A) to switch on connected devices
- video-in-motion





### Contents

### 1. Prior to Installation

- 1.1. Delivery contents
- 1.2. Check compatibility of vehicle and accessories

### 2. Connection schema

### 3. Installation

- 3.1. Interconnecting interface-box and harnesses
- 3.2. Connections to the navigation computer or if existing to the TV-tuner
- 3.3. Connections to radio module
- 3.4. Connecting peripheral devices
- 3.4.1. AV-source(s)
- 3.4.2. Installing AV-source's IR-sensor additionally
- 3.4.3. After-market rear-view camera
- 3.4.4. After-market rear-seat-entertainment
- 3.5. System settings/VI SETTINGS
- 3.5.1. Audio settings
- 3.5.2. Assigning device control for connected AV-source
- 3.5.3. Rear-view camera function
- 3.6. DIP switch settings

### 4. Operation

- 4.1. Activation of the video-in-motion function
- 4.2. Selecting the c.LOGiC as current AV-source
- 4.3. Switching to AV1 and AV2
- 4.4. Picture settings
- 4.5. Button assignment table

### 5. Specifications

6. Technical support

### Appendix A – Device control table





## Legal Information

By law, watching moving pictures while driving is prohibited, the driver must not be distracted. We do not accept any liability for material damage or personal injury resulting, directly or indirectly, from installation or operation of this product. This product should only be used while standing or to display fixed menus or rear-view-camera video when the vehicle is moving, for example the MP3 menu for DVD upgrades.

Changes/updates of the vehicle's software can cause malfunctions of the interface. We offer free software-updates for our interfaces for one year after purchase. To receive a free update, the interface must be sent in at own cost. Labor cost for and other expenses involved with the software-updates will not be refunded.

### 1. Prior to installation

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources.

### **1.1.** Delivery contents



If remote function for a peripheral device shall be used, additional an IR-

Remote cable and Y-adapter are needed, see chapter AV-source(s)





### 1.2. Check compatibility of vehicle and accessories

Requirements				
Vehicle	3series (E46), 5series (E39), 7series (E38), X5 (E53), X3 (E83), Z4 (E85/86) with AUX-input at the radio module (from approx 10/2002)			
Navigation	Navigation system Professional without iDrive (MK2-MK4)			
Limitations				
Factory-audio-AUX-input	The factory audio-AUX-input is used for audio-insertion by the c.LOGiC. Alternative use of the AUX-input is only possible by additional switch-box integration.			
After-market rear-view camera	Compatible with NTSC-cameras only.			



Manual



## 2. Connection schema



Page4

Manual



### 3. Installation

Switch off ignition and disconnect the vehicle's battery! If according to factory rules disconnecting the battery has to be avoided, it is usually sufficient to put the vehicle in sleep-mode. In case the sleep-mode does not show success, disconnect the battery with a resistor lead.

Place of installation is at the navigation computer or the factory TV-tuner (if existing and not removed) and at the radio module.

# If there is a factory TV-tuner inside the car, you have to connect the harness C3C-BM700 to the TV-tuner and not to the navigation computer!

The radio module and navigation computer are located at the rear end for the **3series (E46)**, **5series (E39)** and **7series (E38)** on the left hand side the radio module of the 7series is located behind lining in the car wing).

The **X5 (E53)** radio module is located underneath the boot lining, next to the battery.

The navigation computer is located on the left hand side behind the boot lining.







### 3.1. Interconnecting interface-box and harnesses



1 Plug harness C3C-BM700 into 14pin of interface-box C2C-M700.

Plug female 18pin AMP connector of C3C-BM700 into male 18pin AMP connector of interface-box C2C-M700.





### 3.2. Connections to the navigation computer or – if existing – to the TV-tuner



# If there is a factory TV-tuner inside the car, you have to connect the harness C3C-BM700 to the TV-tuner and not to the navigation computer!



2 Plug blue male 18pin AMP connector of harness C3C-BM700 into blue female 18pin AMP connector of vehicle harness.

(3) Plug blue female 18pin AMP connector of harness C3C-BM700 into blue male 18pin AMP connector of navigation computer or of the factory TV-tuner (if existing and not removed).

**Note:** If an existing factory TV-tuner will be removed the optionally available harness CAB-BMW200 is necessary!



### 3.3. Connections to radio module



Loosen the female Quadlock connector to the radio module. Loosen the black female 12pin connector from chamber B of the female Quadlock connector.

Push the insert from female 12pin connector's plastic cab from the side.

Pin the audio cables of harness C3C-BM700 to the dissambled vehicle's female 12pin connector:

Yellow cable	Pin 3
Blue cable	Pin 4
Black cable	Pin 10

If the chambers of the female 12pin connector are occupied, isolate and remove the existing pins.

Push the black plastic cap onto the female 12pin connector and insert it into the female Quadlock connector. Reconnect the female Quadlock connector to the radio module.









### 3.4. Connecting peripheral devices

It is possible to connect up to 2 after-market AV-sources, after-market rear-view camera and rear-seat-entertainment to the c.LOGiC.

Before final installation of the peripheral devices, we recommend to test-run the c.LOGiC functions to detect incompatibility of vehicle, navigation, factory accessories or peripheral devices as soon as possible.

### 3.4.1. AV-source(s)

The c.LOGiC interface has the possibility to connect and remotely control by navigation buttons up to 2 pre-programmed devices. The device list in the device control table shows the pre-programmed remote channels and the related IR-remote cables STA-xxx which must be ordered separately for the control of the device.





## Manual



Using the respective STA-xxx IR-control cable, interconnect the blue (yellow) female 3pin AMP connector of harness C3C-BM700 and the IR-port of the AV-source 1 (AV-source 2).

Using an RCA-cable, interconnect the female RCA-port AV1 (AV2) of the interface-box C2C-M700 with the AV-output of the AV-source 1 (AV-source 2).

(3) The pink ACC-output wire (+12V max. 1A) of harness C3C-BMW0x can be connected to the ACC-input wires of the connected devices to switch it on. It carries +12V when the navigation computer is running.

### 3.4.2. Installing AV-source's IR-sensor additionally

Additionally to the control via OEM navigation, it is possible to install the original IR-sensor of a connected device. By using the respective Y-adapter (e.g. STA-Y35MM or STA-RJ12) for the IR-Port of the connected device, the controls of navigation AND device's IR-sensor can be connected and used simultaneously. Installation of the IR-sensor is recommended as the controls via navigation are limited, and not all functions may be covered.

### 3.4.3. After-market rear-view camera



(1) Connect the video RCA of the after-market rear-view camera to the female RCA connector R-CAM IN of interface-box C2C-M700.

Connect the green wire of C3C-BM700 to the camera power supply (+12V max. 1A) The green wire is high (+12V) when reverse gear is engaged.

Note: Compatible with NTSC cameras only.





### 3.4.4. After-Market rear-seat-entertainment



Using RCA-cables, connect the rear-seat-entertainment to the female RCA-connector VIDEO OUT of interface-box C2C-M700.

**Note:** As the output is a full output, not shared with the video signal for the navigation system, splitting the video with an RCA Y-cable might give a good enough picture for two rear-seat-entertainment monitors. If not, or if connecting more than two monitors, use a video splitter.

### 3.5. System settings/VI SETTINGS

You must make some settings in the "VI SETTINGS" menu to enable the c.LOGiC's functions.

Press 3x the "MENU" key to access the "VI SETTINGS" menu of the c.LOGiC. Use the right knob to make changes within the "VI SETTINGS" menu. Press 1x the "MENU" key to exit the "VI SETTINGS" menu.





### 3.5.1. Audio settings

Manual

It is necessary to set the audio settings to "AUX" and "CD EMU OFF" to enable the c.LOGiC's functions.

#### 3.5.2. Assigning device control for connected AV-sources

Select control levels setup "CH1:RCxx" for AV1 and "CH2: RCxx" for AV2 in the "VI SETTINGS" menu and assign related IR-codes as described in device control table by turning the right knob.

**Note:** The IR-control channel CH1 is preset to RC-Code 41 compatible DVB-T tuners and CH2 is preset to RC-Code 09 for the usbLiNK.

#### 3.5.3. Rear-view camera function

Set the rear-view camera setting to "RVC: ON" to use the rear-view camera input of the c.LOGiC. After the setting the automatic switching to rear-view camera input is activated when reverse gear is engaged.

**Note:** After the reverse gear is disengaged, the monitor stays on camera video until the vehicle reaches a speed of 10 km/h. To leave the camera video press the right knob.















### 3.6. DIP switch settings

The default DIP switch setting is (already set):

Check after installation the LED status on the C2C-M700 interface. For this, turn off the ignition. After about 1-5min. the status LED should turn off. If the status LED should not turn off, open the C2C-M700 housing, set the DIP switch "3" to OFF and connect the open white/black wire from C3C-M700 harness with ignition (+12V).



1+2 =OFF , 3 = ON (default setting)



1+2+3 =OFF (special case)



Nanual



## 4. Operation

### 4.1. Activation of the video-in-motion function

The video-in-motion function is permanently active without disturbing the navigation performance.

### 4.2. Selecting the c.LOGiC as current AV-source

Selecting the c.LOGiC as current AV-source is activated by pressing the "MODE"-button (depending on the current mode of the system, it has to be pressed several times). After the first activation the system will switch the picture after a few seconds from c.LOGiC-video to factory-video by itself, the audio will still stay on c.LOGiC-audio. Use the picture switch button to select between factory-video and c.LOGiC-

MODE - picture switch button button

video. You can leave the c.LOGiC mode by pressing the "FM" or the "MODE" button.

### 4.3. Switching to AV1 and AV2

In c.LOGiC mode longpress station button **"1**" to switch to AV1 or longpress station button **"2**" to switch to AV2.

### 4.4. Picture settings

The c.LOGiC has its own picture setting mode. In order to enter this mode, set to **"Video Set:ON"** in the "VI SETTINGS" menu. After switching to the Video/Audio level the keys **"1 <> 4"**, "**2 <> 5"**, "**3 <> 6"** can be used for picture settings. (each with short keypress).

You can deactivate the picture setting mode in the "VI SETTINGS" or by turning off ignition.







### 4.5. Button assignment table

The button assignment table shows which functions of the connected devices can be executed by navigation buttons. Once an AV-input is activated, the navigation button in the left column will execute the function described in the corresponding device column. The function description equals the remote control buttons of the device's remote control. On the additional device the writing may vary (e.g. AV instead of Source).





## Nanual



Button assignment table c.LOGiC C2-MK-AUX							
Navigation button	DVB-T tuners	usbLiNK	DVD-player	DVD- changer	iPod <sup>®</sup> -control	Analog-tuner	
1		SOURCE	AV	AV	AV	Display	
1 long	Selection TV/ image format	Selection TV/ image format	Selection TV/ image format	Selection TV/ image format	Selection TV/ image format	Selection TV/ image format	
2		OK / PLAY	PLAY	PLAY	PLAY	SCAN	
2 long	Selection AV2/ Image format	Selection AV2/ Image format	Selection AV2/ Image format	Selection AV2/ Image format	Selection AV2/ Image format	Selection AV2/ Image format	
3	$\leftarrow$	$\leftarrow$	$\leftarrow$	$\leftarrow$	$\leftarrow$	CH -	
3 long	TEXT	EXIT	ZOOM	ZOOM			
4		POWER	POWER	POWER	POWER	POWER	
4 long	Interface On/Off	Interface On/Off	Interface On/Off	Interface On/Off	Interface On/Off	Interface On/Off	
5	EXIT	MEDIA	>>	>>	>>	MUTE	
5 long	SCAN	VOL +	PBC	PBC			
6	$\rightarrow$	$\rightarrow$	$\rightarrow$	$\rightarrow$	$\rightarrow$	CH +	
6 long	EPG	VOL -	STOP	STOP			
7	$\uparrow$	$\uparrow$	$\uparrow$	$\uparrow$	$\uparrow$	VOL +	
8	ОК	OK / PLAY	PLAY	PLAY	PLAY/ENTER	SCAN	
8 long	MENU	SETUP	SETUP	SETUP	LAMP	ADJUST	
9	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	VOL -	
10	CH -	TRACK -	TRACK -	TRACK -	TRACK -	CH -	
10 long				DISC			
11	CH +	TRACK +	TRACK +	TRACK +	TRACK +	CH +	
11 long				DISC			
12			TITLE	TITLE			
12 long			SUBTITLE	SUBTITLE			
13	INFO		DISPLAY	DISPLAY			
13 long	DTV/RADIO		AUDIO	AUDIO			





## 5. Specifications

Operation voltage	10.5 – 14.8V DC
Stand-by power drain	<1mA
Operation power drain	230mA
Power consumption	3W
Temperature range	-30°C to +80°C
Weight	202g
Measurements (box only) B x H x T	90 x 30 x 105 mm

## 6. Technical Support

### Caraudio-Systems Vertriebs GmbH manufacturer/distribution In den Fuchslöchern 3 D-67240 Bobenheim-Roxheim

### Email support@caraudio-systems.de

**Legal disclaimer:** Mentioned company and trademarks, as well as product names/codes are registered trademarks <sup>®</sup> of their corresponding legal owners.